

INSTRUCTION GUIDE

DIMANGO

PRODUCTS

ENCLOSED YOU WILL FIND:

- Motion Detector
- Remote control
- Two 1.5 volt batteries (installed)

TOOLS/SUPPLIES NEEDED:

- Small flat head screwdriver
- Small Phillips head screwdriver

BATTERY NEEDED (not included):



- 9-volt alkaline battery

The Remote Control Motion Detector can be plugged into any standard vertically mounted outlet where the PIR (passive infrared) sensor will detect movement over an area of 30 feet by 110 degrees. It can be armed/disarmed with the enclosed infrared remote control unit. The chime feature can be used to announce visitors at the entrance of the home or office.

Batteries are included in your remote control. When batteries run low, replace them with two 1.5 volt type button cell batteries. Simply open remote control by removing screws and replace batteries.

INSTALLATION

Simply plug the Motion Detector into any standard wall outlet. The Motion Detector has



a locking feature to prevent an intruder from deactivating the siren by removing the alarm from the power source. First, install a standard 9-volt alkaline battery into battery compartment. This will act as a power source in the event of a power failure. Replace the battery compartment cover. To secure the unit to the wall outlet, remove the screw holding the outlet cover plate, plug unit into wall, and insert screw through the hole as shown

ARMING/DISARMING THE ALARM

The unit is armed/disarmed by use of the infrared remote control (additional units sold separately) which operates up to a distance of 25 feet from the alarm. Simply point the remote control at the alarm, press once and release. The alarm must be set to the "alarm" position.


The alarm will "beep" once to indicate that it has been activated and the green LED will light up for approximately 30 seconds to allow exit from the detection zone. The flashing red LED indicates that motion is being detected. The 30 second delay only starts after no motion has been detected for 30 seconds. The alarm will give another beep when the green light turns off indicating that the unit is now armed.

To disarm the unit, simply press the button on the remote control. The unit will beep twice indicating that the alarm is in the "off" mode. The unit will now be switched off. When entering the alarm zone, approximately 10 seconds are given to deactivate the unit before the alarm sounds. Remember to allow for this 10 second delay when testing the alarm.



To announce visitors at an entrance of a home or business, switch the function to the "chime" position. **Note:** Unit must be armed in order for chime to activate. If armed in the chime mode, the unit will only sound the chime. When switching the alarm from alarm to chime position, the alarm must be disarmed.

If the green light is flashing upon your return, there has been an intrusion. The alarm has been set off, and it has reset itself.

Installation



Coverage Area



THE ALARM

The alarm is activated by the PIR sensor. After a 10 second delay, the 110dB high frequency siren will automatically sound once the sensor has detected movement. It will remain on for approximately one minute if no further movement is detected. It will then automatically shut off and reset itself. This will cause the green light to flash and it will continue flashing until the unit is turned off to indicate that an intrusion has occurred.

AC POWER SUPPLY ALERT

In the event that AC Power is lost, the Motion Detector will react by flashing the red LED on the front of the unit and beep once every 20 seconds. This will continue until AC power is restored.

BATTERY BACK-UP

The Motion Detector features a battery back-up function. Should your outlet lose power at any time, the 9-volt battery (not included) will operate properly allowing for continued protection up to 48 hours.

IMPORTANT: The Remote Control Motion Detector is a sensitive electronic product and the following precautions should be followed:

Do not drop the unit.

Do not place the unit close to a source of direct heat.

Do not use different types of batteries or mix old and new ones.

Do not use rechargeable batteries.

The use of an Alkaline battery is recommended. For interior use only.

As with most motion detection devices, pets may activate your unit.

LIMITED WARRANTY

The product you have purchased is guaranteed against defects in workmanship and materials for the period stated on the package. If the product fails due to a manufacturing defect during normal use, return the product to the store where purchased for replacement OR send product to:

Lamson Home Products
25701 Science Park Drive
Cleveland, OH 44122 USA
Attn: Customer Service

Not Covered - Batteries and other expendable items, repair service, adjustment and calibration due to misuse, abuse or negligence are not covered by this warranty. Unauthorized service or modification of the product or of any furnished components will void this warranty in its entirety. This warranty does not include reimbursement for inconvenience, installation, set-up time, loss of use, postage, unauthorized service, or other products used in conjunction with, but are not supplied by, Lamson Home Products.

All requests for replacement must include a **dated sales receipt** (copies accepted) and this guarantee statement. LAMSON HOME PRODUCTS SHALL NOT BE LIABLE FOR LOST PROFITS, INDIRECT, SPECIAL, EXEMPLARY, INCIDENTAL OR CONSEQUENTIAL DAMAGES INCLUDING WITHOUT LIMITATION ANY SUCH DAMAGES DUE TO IMPROPER WIRING OR MISUSE OF THE PRODUCT.

ALSO AVAILABLE FROM DIMANGO PRODUCTS:

- Extend-A-Chime® – lets you hear your existing wired doorbell in remote areas of your home or yard
- Plug-in and Battery Doorbells and Chimes
- On/Off Remote Switches
- Touch and Automatic Lighting Controls

If you have questions or need further assistance, please call Lamson Home Products at: 1-800-LHP-4DIY Mon. - Fri., 9 a.m. - 4 p.m. EST.

U.S. Patent Des: #381,283



LAMSON Home Products
25701 Science Park Drive
Cleveland, Ohio 44122
www.lamson-home.com

Made in China

0203 IS39