

# PUSHBUTTON DIMENSIONS

MODEL #	LENGTH	WIDTH	DEPTH	TYPE
DH1201	3/4"			ROUND
DH1201L	3/4"			ROUND
DH1202	3/4"			ROUND
DH1202L	3/4"			ROUND
DH1203L	3/4"			ROUND
DH1260L	2 1/2"			ROUND STUCCO
DH1263L	2 1/2"			ROUND STUCCO
DH1404L	2 7/8"	1 3/4"	5/8"	RECTANGLE
DH1405L	2 7/8"	1 3/4"	5/8"	RECTANGLE
DH1407	2 7/8"	1 3/4"	5/8"	RECTANGLE
DH1407L	2 7/8"	1 3/4"	5/8"	RECTANGLE
DH1408	2 7/8"	1 3/4"	5/8"	RECTANGLE
DH1408L	2 7/8"	1 3/4"	5/8"	RECTANGLE
DH1504L	2 3/4"	1"	1/2"	RECTANGLE
DH1505L	2 3/4"	1"	1/2"	RECTANGLE
DH1602	5 3/4"	2 5/8"	7/8"	RECTANGLE
DH1605	1 1/4"		7/8"	ROUND
DH1607	1 1/4"		7/8"	ROUND
DH1608L	3"	1 1/4"	1/4"	RECTANGLE
DH1610L	4"	1"	1/8"	RECTANGLE
DH1615L	4"	1"	1/8"	RECTANGLE
DH1630L	2 7/8"	1 1/4"	1/4"	RECTANGLE
DH1631L	2 7/8"	1 1/4"	1/4"	RECTANGLE
DH1632L	2 7/8"	1 1/4"	1/4"	RECTANGLE
DH1633L	2 7/8"	1 1/4"	1/4"	RECTANGLE
DH1635L	2 7/8"	1 1/4"	1/4"	RECTANGLE
DH1636L	2 7/8"	1 1/4"	1/4"	RECTANGLE
DH1637L	2 7/8"	1 1/4"	1/4"	RECTANGLE
DH1641L	3 3/8"	1 1/4"	1/8"	RECTANGLE
DH1650L	2 1/4"		1/2"	ROUND
DH1651L	2 1/4"		1/2"	ROUND
DH1652L	2 1/4"		1/2"	ROUND
DH1653L	2 1/4"		1/2"	ROUND
DH1657L	2 1/4"		1/2"	ROUND
DH1660L	3"	1 1/4"	1/2"	RECTANGLE
DH1665L	3"	1 3/8"	1/2"	RECTANGLE
DH1667L	3"	1 1/4"	1/2"	RECTANGLE
DH1669L	2 3/4"	1 1/4"	1/2"	OVAL
DH1670L	3 3/8"	1 1/2"	3/8"	PINEAPPLE
DH1691L	2 7/8"	1 1/4"	3/8"	RECTANGLE
DH1695L	2 7/8"	1 1/4"	3/8"	RECTANGLE
DH1711L	3 7/8"	1 7/8"	1/4"	GECKO

MODEL #	LENGTH	WIDTH	DEPTH	TYPE
DH1805	2 1/4"	7/8"	5/8"	RECTANGLE
DH1814	2 1/8"	7/8"	5/8"	RECTANGLE
DH1824	2 1/8"	7/8"	5/8"	RECTANGLE
LH1663L / SS1663L	5 1/8"	1 1/4"	1/4"	RECTANGLE
LH1668L / SS1668L	3 1/8"	1 3/8"	1/4"	DIAMOND
LH1673L / SS1673L	3 3/8"	1 3/8"	3/8"	PINEAPPLE
LH1911 / SS1911	3"	1 3/8"	1/2"	RECTANGLE
LH1920 / SS1920	2 7/8"	1 1/4"	3/4"	RECTANGLE
RC807AB	4 1/2"	1"	1/2"	OBLONG
RC810R	4"	1 1/4"	1"	
RC831	3"	1 1/4"	1/2"	OBLONG
RC832	2 5/8"	1 1/2"	1/2"	OVAL
RC835	2"		1"	ROUND